



- #926-C: 1. Open store / Close store at stand alone POS with online  
 2. Send AT command string with "Open Store" job  
 3. Send AT command string with "Close Store" job

1. Open store / Close Store at stand alone POS with Online	2. Send AT command string with "Open Store" job	3. Send AT command string with "Close Store" job	926-C	UP-600	UP-700
No	No	No	0	★	★
		Yes	1		
Yes	Yes	No	2		
		Yes	3		
	No	No	4		
		Yes	5		
		Yes	No	6	
Yes	7				

**OPEN STORE voor modem 2400bps**

**ATS37 = 6 + MS = V34,0,0,0 E0 Q1 &S1 &W0 &W1**

**OPEN STORE voor modem 9600bps**

**ATS37 = 9 + MS = V32,0,9600,9600 E0 Q1 &S1 &W0 &W1**

**CLOSE STORE voor 2400 en 9600bps**

**ATS0 = 1 \N1 \Q3 \J0 &D3 &C1 %E0 %C0 B1 L1 M1**

**Speciale tekens die niet onder de toetsen zitten.**

**[00] 37 [TL] voor %**

**[00] 43 [TL] voor +**

**[00] 61 [TL] voor =**

**[00] 92 [TL] voor \**